

## www.vac-rac.com

info@vac-rac.com

# **SIGN BASE - INSTRUCTIONS**



### **INSTRUCTIONS**

### Please read and follow carefully

### To insert 3 to 4mm sign blade:

- Place the base on a flat surface
- Raise the hinged holder to vertical and push into slots
- Place the 3 to 4mm Foamex sign in the slot and give it a smack downwards (Press a flat piece of wood on the top of the sign, then tap down with a hammer)
- Alternatively unscrew the 3 stainless screws, insert blade and retighten screws - DO NOT OVERTIGHTEN
- Ensure bases and vehicle are clean, then press the unit on a flat area of hood/bonnet, without gaps
- Pressing down expels air make sure all edges of the base are in contact with the vehicle
- To remove the base simply pull up on the pull tab

#### **TIPS**

- Sign units are designed for static vehicles and must be removed from moving vehicles
- They are extremely strong but should be removed in high winds
- The bases can be folded and placed face to face in storage to keep them clean
- Stand the sign blade on the ground rather than the base
- If they pick up metal swarf due to be placed on a garage floor they can be easily wiped clean
- If they accidentally pick up a lot of swarf it can be removed by wiping a strong magnet across the base
- The longer the base is attached the more secure it becomes, air and water are gradually expelled